



Surface SWYPE for Hexavalent Chromium Cat. No. 769-1030

1. Lightly spray the area or item (e.g., workbench, tool, control knob) with Cleaning/Developing Solution for Hexavalent Chromium Cat. No. 769-1070.
2. Wait at least 30 seconds and then wipe with a Surface SWYPE pad.
3. Allow 3 minutes for the color to develop on the pad. Hexavalent chromium will produce a purple/violet color.

Notes: *Although the color is stable, it is recommended that you read the color after 3 minutes.*

Known interference: Iron, copper, molybdenum, and vanadium

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.