



Exciting News!

On July 15, 2019, SKC Inc. acquired Colormetric Laboratories, Inc. (CLI).

SKC is excited to add CLI surface and dermal assessment and control tools to our highly respected, long-standing sampling solutions that help you maintain the health and safety of workers. SKC looks forward to continuing to provide the same great CLI products with excellent customer and technical support. Learn more about SKC Inc. at <https://www.skcinc.com/about>.

PERMEA-TEC Sensor for Acid/Base Cat. No. 769-3006

The PERMEA-TEC Sensor colorimetric screening method determines the effectiveness of chemical-protective gloves and clothing under actual use conditions. CLI's microencapsulation detection indicator changes color, indicating permeation for many common acids and bases. Results enable professionals to select the gloves/clothing best suited for protection, acceptance, and cost-effectiveness.

Easy-to-use PERMEA-TEC sensors are adhered to a worker's skin at points of greatest contact and abrasion before gloving or covering, observed for color change at time intervals, and sent to an accredited laboratory for analysis if desired.

Instructions for Use

To determine a user-safe time period for the particular glove, **double gloving is recommended.**

1. Affix PERMEA-TEC sensors to the thumb, middle finger, and palm on the outside of the glove currently being worn. Place the glove to be evaluated over the first glove.
2. After one hour, remove the outside glove and the underlying PERMEA-TEC sensors.
3. Evaluate the sensors for breakthrough. A positive indication of breakthrough results in a color change. An acid will change from a neutral (orange) color to fuchsia/magenta at pH 3. A base will change from a neutral (orange) color to blue at pH 9.5.
4. If no breakthrough is indicated, apply fresh PERMEA-TEC sensors and continue to wear the outside glove for another hour. Follow Steps 2 and 3 to determine if breakthrough has occurred.
5. Repeat Steps 3 and 4 to determine a user-safe time period for gloves.

Other PERMEA-TEC sensors are available for:

Aromatic Amines:	MDA, aniline, o-toluidine, methylene-bis(2-chloroaniline) (MOCA)
Aromatic Isocyanates:	TDI, MDI
Aliphatic Isocyanates:	HDI, HMDI
Aliphatic Amines:	N,N-dimethylcyclohexylamine, triethanolamine, diethanolamine, and triethylenediamine
Phenols:	Bisphenol A
Solvents	

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to <http://www.skcinc.com/warranty>.